

SUBJECT: UPDATE OF THE CORROSION SEVERITY ZONE MAPS IN THE AIRCRAFT MAINTENANCE MANUAL (AMM) CORROSION CONTROL MAINTENANCE PRACTICES DATA MODULE (DM)

To all Customers, Operators and Service Centers:

Date: May 27/24

Effectivity: All PC-12 Series Aircraft.

This Service Letter is issued to draw attention to the following information:

UPDATE OF THE CORROSION SEVERITY ZONE MAPS IN THE AMM CORROSION CONTROL MAINTENANCE PRACTICES DM

The corrosion severity zone maps are included in the corrosion control maintenance practices DM of the AMM, the maps have been updated to include the most recent knowledge and in-service experience of corrosion.

The DM updated in the AMM is as follows:

- Data Module 20-40-00-00A-901A-A, Corrosion Control - Maintenance Practices

Operators that require additional information should contact their authorized Pilatus Service Center, or Pilatus Customer Support on www.pilatus-aircraft.com → contact us

INTENTIONALLY BLANK